



TROUBLE SHOOTING

PANEL TRACK SYSTEM

Problem

Cord is hard to pull

Check

Too much tension on cord

Solution

Remount the tension pulley.

A panel has separated from the others.

Slightly pull forward (toward the room) on the bottom on the front carrier and push back (toward the window) on the bottom of the carrier behind it. This will allow you to slide the back panel behind the front panel.

Panels hang crooked

Check to see if panels are attached straight.

Reattach panels to track

Panels hitting the floor

Check to see if panels are properly placed on glides.

Reattach panels

Are brackets mounted too low?

Move brackets

Still have questions? Call our hotline at 1-800-726-3380

8801 Corporate Square Court, Jacksonville, FL 32216
www.vistaproducts.com