



TROUBLE SHOOTING

ROMAN SHADES

Problem

Shade hangs crooked

Check

Check all cords on the back of the shade to be sure they have not wrapped around a cord clip

Solution

Position cord clips in line with the others and unwrap cord from clip.

Are pull cords even?

Shade binds when raising or lowering

During shipment, a cord may become pinched between pulley and pulley housing

Lift the valance and reposition the cord over the pulley wheel.

Still have questions? Call our hotline at 1-800-726-3380

8801 Corporate Square Court, Jacksonville FL 32216

www.vistaproducts.com